
CE F©

- Compatible for 3.5" HDD and 12.7mm slim optical drive.
- Hot swappable
- anti-shock and tool less design
- NSS connector to give over 50,000 cycle hot swaps.

MRA359 Manual

MRA359



Features: • Accommodates both 3.5" SATA hard drive and 12.7mm slim optical drive

Supports hot swaps

Unique anti-shock design patented screw-less mechanism

Specifications:

- Fit all 3.5" Serial ATA hard drives
- Supports hot swap • Supports SATA II (3.0Gb/s)
- Housing Assembly: 184mm(L)x148mm(W)x42mm(H) • Interface: SATA or PATA for slim optical drive SATA for hard drive


• Nss connector gives over 50,000 cycle hot swaps

- Weight: 310g
- Operating Temperature: 0~55°C


Package Content:

Fackage Content.	
MRA359	1Pcs
SATA data cable	1Pcs
Fan power & access SATA cable	1Pcs
User manual	1Pcs
Screws 3x6pwn	4Pcs
Screws 2x3pm	3Pcs


Installation:




by pressing buttons of both sides.



Push 12.7mm slim optical drive into the slim drive bay.




After pushing the slim optical drive into position to align with the front panel, use a magnetic screwdriver to secure three screws to the optical drive.




Place MRA359 into an available 5.25" bay in the chassis and secure with


Connection :



2. Insert one end of the SATA 7P cable to MRA359 , another end(7P) to either the mother board or the SATA RAID card. the corresponding port on the motherboard



Inserting the Hard Drive:



1. Release the door puller to eject the front door panel

Removing the Hard Drive:


1.Smoothly pull the spring lock to open the front door. Make sure the lock is at a removable position to open, or it would get damaged. 2.Carefully take the HDD out of the product.

↑ The temperature of HDD may reach over 50℃. It's not hot enough to burn hand, but becareful.




1. Hard drive is a precise and accurate device. Read the manual in advance and treat it carefully.

- 2. Do not eject the HDD while it is working.
- 3. Hold the HDD by its edge instead of touching the PCB on it.
- 4. Wingsonic will provide maintenance for the product malfunction problems, but not be responsible for any software or data



硬碟抽取盒

一个神奇的3合一小型多媒体储存装置



- NSS专利连接器,支援50,000次热插拔

MRA359 使用説明書

MRA359



产品特色:

- 可同时搭配3.5″ 硬碟+12.7mm薄型光驱 支援3.5″ SATA硬碟热插拔
- 防震结构设计, 专利免丝结构,
- NSS专利连接器, 支援50,000次热插拔

产品规格:

- 适用於所有3.5" SATA硬碟
- 支援热插拔 • 支援 SATA II (3.0Gb/s)
- 产品规格: 184mm(L)x148mm(W)x42mm(H)
- 工作界面: SATA
- 重量: 310克 • 工作温度: 0--55℃


包装内容:

螺丝 2x3 Pm


MRA359 硬碟盒 1Pcs 1Pcs SATA电源 線 SATA 连接線 1Pcs 使用说明书 1Pcs 4Pcs 螺丝 3x6 Pwn


3Pcs


安装步骤:




按两边按扭, 取出上档板








请确认薄型光碟机对准并密合於 前面板,并以螺丝起子将三颗光 碟机架用螺丝锁固定;




安装MRA359於机壳上的5.25" bay并以螺丝锁固於机壳;

- 1. 请将SATA 15P 端连接至MRA359之15P端口,大4P电源 编电脑主 机电源相接,小4P LED 維接至MRA359后端之4P LED端。
- 2. 请将SATA 7P讯号 線 端连接MRA359,另一端插入主机板讯号埠。



放置硬碟步骤:



1. 轻轻推动HDD-ROM解锁按扭(从左至右), 使面板弹出;

2. 放入3.5 " 硬碟(注意硬碟標識 向上),

2. Put the 3.5" HDD into the

3. close the front panel.

1. After inserting HDD and closing the front door, carefully


2.If the HDD is inserted backward into the tray, forcing the

push the tray until it is seated into position. Excessive


device may damage the MRA 359 HDD-ROM.

force may damage its mechanical parts.

MRA359



3. 关上面板。



1.插入硬碟並關上前面板時,請小心輕輕推動前面板 至鎖住狀態,以免機構零件受損.

2.如果硬碟插入方向錯誤,請不要關閉前門,如強行關 閉,MRA359 HDD-ROM會被損害.

卸下硬碟步驟

- 1.輕輕拉動HDD-ROM解鎖按鈕,使面板彈出. 2.打開前面板, 取出3.5"硬碟,再確實緊關上面板.
- 1. 當工作狀態下禁止卸下硬碟. 2. 硬碟表面溫度有可能高達50°C, 雖不會造成燙傷, 但仍要小心, 請接觸硬碟邊緣, 不要觸摸上面的電
- 1. 硬碟是精密设备,要特别注意,请预先阅读使用者说明书2. 当工作状态禁止卸下硬碟
- 2. 当工作机总票正即下废除 3. 请接触硬碟的边缘,不要触摸上面的线路板 4. 对于产品故障问题,本司提供维修服务,不承担任何产品的 软硬体或资料遗失等责任。



CE F©

• 可同时搭配3.5″ 硬碟+12.7mm薄型光驱 • 支援3.5″ SATA硬碟热插拔

• 防震结构设计,专利免丝结构,